

# Download File PDF Hybrid Workshop Manual

#Jenny



Finally I get this ebook, thanks for all these I can get now!

#Rio



Cool! I'am really happy

#Markus Jensen



I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu



wtf this great ebook for free?!

#Che Salsa



My friends are so mad that they do not know how I have all the high quality ebook which they do not!

#Diego Butler



so many fake sites. this is the first one which worked! Many thanks

**CANTER**  
ECO HYBRID

## Shop Manual

### GROUP INDEX

electrical

GENERAL.....	54-00A
SPECIFICATIONS.....	54-00B
STRUCTURE AND OPERATION.....	54-00C
TROUBLESHOOTING.....	54-00D
POWER, CHARGE AND GROUND CIRCUIT.....	54-01
ENGINE STARTING, STOPPING AND PREHEATING CIRCUIT.....	54-02
LIGHTING CIRCUIT.....	54-03
METER CIRCUIT.....	54-04
INDICATOR AND WARNING LAMP CIRCUIT.....	54-05
CAB SIDE ELECTRICAL CIRCUIT.....	54-06
CHASSIS SIDE ELECTRICAL CIRCUIT.....	54-07
OTHER CIRCUIT.....	54-08
ELECTRICAL EQUIPMENT INSTALLATION POSITIONS.....	54-10
INSPECTION OF ELECTRICAL EQUIPMENT.....	54-11
STARTER AND ALTERNATOR: ON-VOLTS/E INSPECTION AND ADJUSTMENT.....	54-12
CONNECTOR CONFIGURATION CHART.....	54-14

### FOREWORD

This Shop Manual is published for the information and guidance of personnel responsible for maintenance of Mitsubishi Fuso CANTER series truck, and includes procedures for adjustment and maintenance services. We earnestly look forward to seeing that this manual is made full use of in order to perform correct services with no wastage.

For more details, please consult your nearest authorized Mitsubishi Fuso dealer or distributor. Kindly note that the specifications and maintenance service figures are subject to change without prior notice in line with improvement which will be effected from time to time in the future.

JUNE 2009

Applicable models  
FE

APPLICABLE SERVICE BULLETINS FOR THIS MANUAL INDEX

©2009 Mitsubishi Fuso Truck & Bus Corporation

[Download PDF version of :](#)  
**Hybrid Workshop Manual**